



Ventilation Tube Adaptor Installation Guide

Step 1. Insert adaptor **part B** in the male end of the vent tube **part C**

Step 2. Make sure that AUSFAN air fan is fitted to hanging device

Step 3. Slide AUSFAN ventilation fan **part A** into adaptor **part B**

